

EX SERIES

600 / 750 / 1000 / 1200

Electric Cassette Steps



series
AVS STEPS

SERVICE BULLETIN SB 089

SERVICE BULLETIN SB 089

Replacing Bottom Tread Corner


1. Remove the bottom corner piece using a 3mm allen key



2. You may need to use the end of the allen key to lever the tread corner off



3. View with bottom tread corner removed



4. Replace the broken tread corner as below, using thread lock on the M5x30 counter sunk bolt to 5nM torque



Tread Corners EXE Steps IDENTIFICATION

6010153
LH Upper

6010154
RH Upper



6010155
LH Lower

6010156
RH Lower